




IMPORTANT!
KEEP FOR FUTURE REFERENCE.

Read these instructions carefully before use.

Your child may be hurt if you do not follow the instructions. Adult assembly required.

Instruction Leaflet

Bambino Bouncer




Suitable for babies from birth.

WARNING: Not recommended for children who can sit up by themselves (6 months approximately, until 9kg). Adult assembly required.

Complies with: BSEN 12790 - 2009. Customer Care Line: 01454 326 568

Parts list

1. Rear frame bar
2. Left side frame
3. Right side frame
4. Left head frame
5. Right head frame
6. Foot frame
7. Seat cover and harness



Frame assembly.





1. Fold out the plastic corners of the rear frame bar and connect the left and right side frames, then snap the plastic corner back in to place. Fig 1.

NOTE The rubber feet on the rear frame bar should be facing downwards.

2. Fit together the left and right head frame by pressing in the silver spring clip and slotting the two sections together. Make sure the silver clip clicks in to the hole. Fig 2.

3. Push the ends of the foot frame in to the upper holes of the head frame joints until they click in place. Pull the foot frame to ensure it is locked in place. Fig 3.



4. Connect the ends of the side frames in to the lower holes of the head frame by pressing in the silver clips and pushing together. Ensure the silver clips are seated in their holes by pulling the seat frame. Fig 4.



Seat cover assembly.


5. Slide the seat cover on to the top of the head frame and wrap the bottom around the foot frame. Fig 5.

6. Turn the bouncer over and connect each buckle to the opposite sides so that the flaps cross over. Pull on the buckles to ensure they are secure. Fig 6.



Feet placement.

7. Slide the rubber feet on the side frames towards the bends at the front of the frames. This ensures the Bouncer is sitting correctly. Fig 7.






To use the bouncer.

8. Squeeze the sides of the buckles, pull them apart and lay the crotch flap open. Fig 8.

9. Lay baby in the bouncer, lift the crotch pad up and reconnect the harness clips on both sides. Pull the harness clips to ensure they are secure. Fig 9.

10. Adjust the waist strap by tightening or loosening the free ends of the straps so it's a snug comfortable fit. Fig 10.



CAUTION - The harness should be worn and correctly adjusted at all times.

CAUTION - Do not make any adjustments when the child is in the reclined cradle.

General Care:

- The correct use and maintenance of this reclined cradle is essential.
- In some climates mould and mildew can affect the fabric on the reclined cradle.
- Always store the reclined cradle in a dry place.
- This reclined cradle does not replace a cot or a bed. Should your child need to sleep, then it should be placed in a suitable cot or bed.
- Please dispose of packaging material as plastic bags can be dangerous to young children.

Cleaning:

- The cover may be sponge cleaned in situ using a mild detergent solution.
- For heavy soiling the cover may be removed and hand washed using a mild detergent solution.
- Lie cover flat and dry in a well ventilated area out of direct sunlight.
- Do not use bleach, ammonia based or abrasive cleaning chemicals.
- Do not dry clean.
- The frame and plastics may be cleaned with a damp cloth and a mild detergent solution and dried with a soft cloth.

Maintenance:

- Regularly inspect all tubes and fixings. Ensure that all are secure before each use of the product.
- Do not use the reclined cradle if any components are broken or missing.
- Regularly inspect fabric and stitching and check that it is undamaged.
- Do not use accessories or replacement parts other than those approved by the manufacturer. Failure to do this may invalidate your warranty.

Safety Warnings:

- **WARNING:** Your child's safety is your responsibility.
- **WARNING:** Do not use the reclined cradle once your child can sit unaided.
- **WARNING:** Never leave the child unattended.
- **WARNING:** This reclined cradle is not intended for prolonged periods of sleeping.
- **WARNING:** It is dangerous to put this cradle on an elevated surface, e.g. a table.
- **WARNING:** Always use the restraint system. Always ensure that the harness is fastened and adjusted at all times.
- Only use on a flat, level floor surface.
- Do not use near stairs / steps.
- Do not position the reclined cradle close to a source of heat e.g. household electric fires etc.
- Do not position close to items such as curtains and electrical flexes as they could pose a danger of suffocation or strangulation.
- Never use in a vehicle as a child restraint.
- Never pick the reclined cradle up when the child is in it.
- Do not adjust the reclined cradle when the child is in it.
- Store the reclined cradle out of the reach of children when not in use.
- Do not allow other children to play with the reclined cradle.

The product complies with
BS EN 12790 : 2009.

Imported by The Red Kite Baby Co Ltd. , 35
Lavenham Road, Beeches Industrial Estate, Yate,
Bristol, BS37 5QX.

